


## DC-200/40-PZ-Si

Single-mode, polarizing double-clad Si fiber



# LARGE AREA, SINGLE-MODE FIBER

The DC-200/40-PZ-Si is a passive, large mode area, single-mode core embedded in a high NA multimode fiber structure. It is substantially similar to our DC-200/40-PZ-Yb active ytterbium-doped fiber apart from the core material and can be used to optimize procedures that will be used with the active version.

With a mode area of more than 700  $\mu m^2$ , this fiber represents the best in flexible single-mode passive fibers. The single-polarization core improves the PER compared to normal PM fibers.

#### The single-mode advantages

Our single-mode fibers offer several advantages compared to standard multi-mode large area fibers:

- · Excellent output stability
- · Outstanding beam quality
- · No need for tight coiling
- No coiling-induced mode area compression



Multi-mode pump light is guided by our proven air clad technology, ensuring low loss, high damage threshold, and a large numerical aperture. The large NA relaxes the tolerances on coupling optics and facilitates the use of lower brightness diodes.

#### Coil Control

Coil Control ensures that the fiber coils in one plane leading to superior mode stability. Depending on the wavelength, we recommend a 25-40 cm coiling diameter and operating the fiber in the slow (in-plane) axis.

#### **Features**


- · Single-mode polarizing
- Large mode area
- High NA circular pump core
- Coil Control ensuring excellent stability

Also available in a Yb-doped version: DC-200/40-PZ-Yb

### **SPECIFICATIONS**

Signal core	
Mode properties	Single-mode
Beam quality, typical @ 1064 nm	M <sup>2</sup> < 1.2
Mode-field diameter, 1/e² @ 1064 nm [μm]	31 ± 2
Numerical aperture @ 1064 nm	≈ 0.03
Multi-mode pump core	
Numerical aperture @ 950 nm	0.60 ± 0.05
Polarization parameters	
Birefringence Δn @ 1100 nm	≥ 1 x 10 <sup>-4</sup>
Physical properties	
Signal core diameter [µm]	≈ 40
Pump cladding diameter [μm]	200 ± 3
Outer cladding diameter [µm]	450 ± 20
Coating diameter [µm]	540 ± 30
Outer and pump cladding material	Pure silica
Coating material, single-layer	High-temperature acrylate
<u> </u>	<u> </u>

#### Typical near field intensity profile



All NKT Photonics fiber products are produced under our quality management system certified in accordance with the ISO 9001:2015 standard.

